

1



A special pictogram in the corner of the shipping box indicates where the cardboard is bonded, which is also the best place to tear off the side.

2



Separate the glued sides of the box in the indicated place.

3



By tearing off the front wall of the box you can grab and take out the dispenser.

4



The dispenser can be placed on a shelf in a storage place. This provides additional protection against outside dirt until the products are used in the operating theatre.

5



The packaging with an EAN 128 bar code facilitates the logistics process, better warehouse management and easy identification of the content due to the front label.

6



The dispenser is multiple-use packaging with a special flap and dispensing opening. It can be opened with a handle so you can easily and quickly take out a single sterile product from the packaging.

7

